

COVID-19 (Coronavirus) Update

April 16, 2020

Periodic Cleaning & Sanitizing of Electronic Gaming Equipment

Bingo King/Trade Products supports responsible charitable gaming and recommends that its customers take extra precautions to stop the spread of COVID-19 in the jurisdictions where Bingo King's products are in use.

Bingo King recommends that all of its gaming products and electronic devices be surface cleaned after each use with disinfectants that have been recommended by the government to combat Coronavirus and other communicable diseases.

Cleaning and Disinfecting your Bingo King Products

- · Clean the surfaces with a dampened, non-abrasive cloth, removing any dust or debris.
- · Apply a disinfecting solution with disinfecting wipes, or dampen a clean, non-abrasive cloth with a disinfecting cleaning solution (remove excess liquid). Do not spray products directly.
- Allow the disinfectant to remain wet; disinfected surfaces should air dry.
- · When a label cautioning against harsh cleaners is present, please check the disinfectant. An alternate from the approved list may be required.

Bingo King advises that charitable gaming operators follow the government's guidance and/or orders for social distancing, and for any volunteers, employees, and patrons to use things like face masks, gloves, and hand sanitizers to help stop the spread of Coronavirus within a charitable gaming environment.

Bingo King/Trade Products is not liable for any damage or injury resulting from improper cleaning, or from the failure to adequately clean and disinfect products between uses.

Please contact the Bingo King Technical Assistance Center at 866.405.3482 if you have any questions.